HANDHELD GAME CONSOLE
M28 | Instructions



1 / CHARGE

Connect a USB-C cable to the console and a 5 V / 2 A USB power supply. Allow approximately 5–8 hours to charge, as stated in the supplied manual.

2 / SWITCH ON

Use the ON–OFF switch on the top edge. Adjust the rear folding stand if you want to rest the console on a stable surface.

3 / CHOOSE A GAME

Use the directional control to highlight a game or menu option. Press Start or A to enter. From the game list, press B to return to the main menu.

4 / IN-GAME MENU

Press Select + Start together to open the game menu. Choose pause, save, load or exit with the directional control, then confirm with A. Save your progress before exiting.

SETTINGS

Open Settings from the main menu. Use the directional control to select an item, then press Start or A to enter or confirm. Options include language, backlight, factory reset and system information. A factory reset restores settings, so check your saved data first.

CONTROLS AT A GLANCE

- Directional pad and sticks: navigation and gameplay.
- A / B / X / Y: game functions; A confirms menus and B goes back.
- Start / Select: game and menu functions.
- L1 / L2 / R1 / R2: shoulder controls; functions depend on the game.

CONNECTIONS & STORAGE

- USB-C charging port.
- TF/microSD card slot: the supplied manual lists support up to 256 GB.
- 3.5 mm stereo headphone socket.
- Built-in speakers.

Place compatible game files in their corresponding system folders. Use only files you are entitled to use. Game compatibility and performance vary by emulator and title.

CARE & SAFETY

- Children under 14 must use the console with adult supervision.
- Keep packaging, plastic bags and small parts away from children under 3. Suffocation hazard.
- If the console has been at 0 °C or below, leave it at room temperature for two hours before use.
- Do not open the case or make unauthorised modifications.

Keep these instructions for future reference.