

RETRO HANDHELD GAME CONSOLE

R36S | R36S-64G | Shortcut quick reference

RETROARCH SHORTCUTS

Select + X	Open quick menu
Select + Start, twice	Quit current game; save first
Select + R2	Toggle fast forward
Select + L2	Rewind
Select + L1	Load state from current slot
Select + R1	Save state to current slot
Select + Y	Show / hide frame rate (FPS)
Select + B	Take a screenshot
Select + A	Pause

MEDIA PLAYER

L / R	Rewind / fast forward
A	Pause
Select + Start	Exit

STORAGE REFERENCE

The **gamedata** folder on card 2 stores emulator settings, saves and resources. Back up your card before changing files.

Dosbox:	DOS
Drastic:	Nintendo DS
Hatari:	Atari ST
Openbor:	OpenBOR
Opentyrian:	OpenTyrian
Ppsspp:	PSP
Remappings:	RetroArch button mappings
Scummvm:	ScummVM
Retroarch:	RetroArch
mupen64plussa:	Nintendo 64
themes:	system theme resources

OTHER EMULATORS

PSP:	R3 opens the emulator menu.	
Nintendo DS:	**R3**	Open emulator menu
	L2	Change screen layout
	R2	Switch single / dual screen
	Right stick	Move stylus
	L3	Stylus click
OpenBOR / Pico-8:	Start opens the menu.	

L3 and R3 mean pressing the left or right analogue stick down.

CHARGING & CONNECTIONS

Use the USB-C charging port with a 5 V / 2 A supply. The source lists approximately 2 hours to charge. The separate USB-C OTG port is for data. A 3.5 mm headphone socket is provided.

REFERENCE NOTE

Shortcuts depend on the installed firmware and emulator. This sheet translates the supplied shortcut reference; it is not a complete operating manual.

Keep these instructions for future reference.