MY FIRST PLAY PHONE

S3 | Camera & media player instructions



SWITCH ON & CHARGE

Hold **Power to** switch on or off. Press briefly to wake the screen.

Charge through USB-C using a 5 V / 1 A supply. Recharge when below 15%. After low-battery shutdown, charge for 1–2 hours.

If it will not switch on after long storage, charge for 15 minutes, then briefly press Reset and switch on again.

BASIC CONTROLS

Power: hold on/off; press to wake.

Volume – / +: lower / raise music volume.

Home: return to the previous screen; on the home screen, lock the screen. Swipe the screen saver to return home.

Reset: if the device freezes, press the recessed reset button to switch off, then restart.

GALLERY & PLAYER

Open Gallery, swipe to choose a photo and tap to view. Options include zoom, wallpaper and deletion.

Open **Player** to browse videos. Hold a selected video for properties and deletion options.

GAMES & LEARNING

Open **Game**, swipe to select and use touch controls.

ABC Learning provides interactive letters.

Timer, stopwatch and torch are also available.

ABC

CARE & SAFETY

Do not shine the torch into anyone's eyes.
Do not force cards or cables into sockets.
Use the specified 5 V / 1 A supply.

SPECIFICATIONS

2.8-inch colour display • JPG photos • AVI video • microSD up to 32 GB • DC 5 V charging.

MEMORY & FILES

Insert a TF/microSD card in the correct direction until it clicks, then restart the device. Supports up to 32 GB.

Connect to a computer with a USB-C data cable to copy or delete stored pictures and videos. Back up files before deleting them.

CAMERA & VIDEO

Open **Camera** and tap the shutter to take a photo. Use left/right arrows to change scenes and the camera-switch icon for front/rear cameras.

Open **Video** and tap Record to begin. Tap again to stop. Select playback to watch your recording.

MUSIC & RECORDER

Open **Music** to play audio, choose previous/next tracks, adjust volume or view the playlist. MP3 is supported.

Open **Recorder** to record sound. Use the on-screen controls to pause, save and replay recordings.

SETTINGS & BLUETOOTH

Settings includes date/time, language, startup volume, brightness, screen timeout and background image.

To use **Bluetooth headphones:** put them in pairing mode, open Bluetooth settings, search for a device, select it and pair. Keep the headphones within about 3 m. Retry if pairing fails.

Study mode can be scheduled by time and day. Settings also includes factory reset and software version. Back up files before resetting.

Keep these instructions for future reference.