HUINA

SKU1532


# WHEEL LOADER


## ENGLISH INSTRUCTIONS



## 01 INSTALL BATTERIES

1. Ensure the power switch is OFF.
2. Open the battery cover, insert the 3.7V Li-ion rechargeable battery pack (included) and connect it to the vehicle battery connector.
3. Place the battery pack in the compartment, refit the cover and tighten the screws.




**Remote control:** 2 × 1.5 V AA alkaline batteries (not included).

Open the cover, insert batteries following the marked polarity, then refit and tighten the screw.

Replace batteries if the indicator fails to light.

## 02 CHARGE VEHICLE BATTERY

1. Ensure the power switch is OFF and remove the battery pack from the vehicle.
2. Connect the battery pack to the supplied USB charging lead.
3. Connect the USB plug to a USB power adaptor with 5V output (2A).
4. Disconnect the charging lead when charging is complete.




| CHARGING INDICATOR: | |
|---|---|
| Off before charging | Charging ready |
| On while charging | Charging in progress |
| Off after full charge | Charging complete |

| | |
|---|---|
| Output (charger) | 3.7V ⎓ |
| Output (USB adaptor) | 5V ⎓ 2A |

Charging time: 1 – 2 hours

## 03 PAIR REMOTE (2.4GHz)

1. Turn the vehicle power switch ON.
2. Within 5 seconds, turn the remote control ON.
3. Wait until the remote indicator stops flashing. The remote is now paired and ready to use.

**Remote power switch**




Pair within 5 seconds of switching the vehicle on.

## 04 REMOTE-CONTROL FUNCTIONS


### Button positions

| | |
|---|---|
| Upper-left round face button | Raise bucket |
| Upper-right round face button | Lower bucket |
| Lower-left round face button | Lights on |
| Lower-right round face button | Lights off |
| Centre triangle button | Automatic demonstration |
| Slide switch | Power on/off |

### Key to controls

1. Left drive stick
2. Right drive stick
3. Raise bucket
4. Lower bucket
5. Lights on
6. Lights off
7. Automatic demonstration

### Driving functions (use both sticks together)




## 05 BATTERY CARE AND SAFETY

1. Correct battery polarity.
2. Do not mix different types of batteries or old and new batteries.
3. Use only the recommended batteries.
4. Do not short-circuit terminals.
5. Remove exhausted batteries from the remote control.
6. Never recharge non-rechargeable batteries.
7. Remove the rechargeable battery pack from the vehicle before charging.
8. Charge rechargeable batteries under adult supervision.
9. Regularly check the charging lead, plug, shell and related parts. If any part is damaged, stop using the product until the damage has been repaired.
10. Keep clear of sharp parts.
11. Do not break off the antenna of the controller.

**WARNING:**
**CHOKING HAZARD** — Small parts.
Not suitable for children under 3 years.

Keep these instructions for future reference. • Made in China