
HUINA DUMP TRUCK

English instructions • SKU1534




01 INSTALL BATTERIES IN THE VEHICLE

1. Switch off the vehicle.
2. Open the battery cover, install the 3.7V Li-ion battery pack and connect it to the vehicle power supply port as shown.
3. Place the battery pack in the compartment.
4. Refit the battery cover and tighten the screws.



02 CHARGE THE VEHICLE BATTERY

1. Switch off the vehicle and remove the battery pack from the vehicle.
2. Connect the battery pack to the USB charging port using the included USB charging lead.
3. Connect the USB plug to a 5 V, 2 A USB power adaptor (not included).
4. The charging indicator is off before charging, on while charging, and off again after full charge.
5. Disconnect when fully charged.




CHARGE TIME

Charge for approximately 1–2 hours.
Disconnect when fully charged.

BATTERY SPECIFICATIONS	
Battery specifications: 3.7V Li-ion	Uncharged state: charging indicator light always off
USB PARAMETERS	Charging state: charging indicator light on
Input: 5V 2A	Full charge state: charging indicator light off
Output: 3.7V	Charging period: 1–2 hours

03 INSTALL BATTERIES IN REMOTE AND PAIR

1. Open the remote control battery cover.
2. Install 2 x 1.5V "AA" alkaline batteries (not included), matching the polarity markings.
3. Refit the battery cover and tighten the screws.



2 x 1.5V "AA" BATTERIES
(Not included)

2.4 GHz Pairing:

This model uses a 2.4 GHz connection.

1. Switch on the vehicle.
2. Within 5 seconds, switch on the remote control.
3. Wait until the remote indicator stops flashing.

   Pairing is complete.

When the indicator light of the remote control is not lit, it indicates low batteries. Replace the batteries with new 1.5V "AA" alkaline batteries.

04 REMOTE-CONTROL FUNCTIONS

CONTROL	FUNCTION
Upper-left round face button	Raise tipper body (cycle)
Upper-right round face button	Lower tipper body (cycle)
Lower-left round face button	Lights on
Lower-right round face button	Lights off
Centre triangle button	Automatic demonstration
Left joystick	Left drive stick
Right joystick	Right drive stick
Bottom slide switch	Power on/off

DRIVING OPERATIONS	
Both sticks forward at the same time	Move forwards
Both sticks backward at the same time	Move backwards
Left stick forward and right stick backward	Turn right
Left stick backward and right stick forward	Turn left

05 BATTERY CARE AND SAFETY

1. Insert batteries with the correct polarity.
2. Do not mix different types of batteries or new and old batteries.
3. Use only the recommended batteries or the same types of batteries.
4. Do not short-circuit the supply terminals.
5. Remove exhausted batteries from the car.
6. Never recharge non-rechargeable batteries.
7. Remove the rechargeable battery pack from the toy before charging.
8. Rechargeable batteries are only to be charged under adult supervision.
9. Regularly check the USB charging lead, plug, shell and related parts for damage. If any part is damaged, stop using the equipment until the damage has been repaired.
10. Keep clear of sharp parts. Do not break off the antenna of the controller.

⚠ WARNING: **CHOKING HAZARD** — Small parts. Not suitable for children under 3 years.

Keep these instructions for future reference. • Made in China