
HUINA EXCAVATOR

English instructions • SKU1531




01 INSTALL BATTERIES IN VEHICLE

1. Switch off the vehicle.
2. Open the battery cover.
3. Connect the supplied 3.7 V rechargeable battery pack to the vehicle connector as shown.
4. Place the battery pack in the compartment.
5. Refit the cover and tighten the screws.



02 CHARGE VEHICLE BATTERY

1. Switch off the vehicle and remove the battery pack from the vehicle.
2. Connect the battery pack to the included USB charging lead as shown.
3. Connect the USB plug to a 5 V, 2 A USB power adaptor.
4. When charging is complete, disconnect the charging lead. Do not leave charging unattended.




USB SPECIFICATIONS
Input: 5 V 2 A
Output: 3.7 V

CHARGING INDICATOR	
Before charging:	off
Charging:	on
Fully charged:	off
Charging time:	1–2 hours

03 INSTALL REMOTE CONTROL BATTERIES


1. Open the remote control battery cover.
2. Install 2 × 1.5 V "AA" batteries (not included) following the marked polarity inside the battery compartment.
3. Refit the cover and tighten the screws.



Use 2 × 1.5 V "AA" batteries (not included).


04 PAIR REMOTE CONTROL (2.4GHz)

1. Install the vehicle battery and switch the vehicle power switch to ON.
2. Turn on the remote control.
3. Wait until the remote indicator stops flashing. Pairing is then complete.



05 REMOTE CONTROL FUNCTIONS

1. Move forwards / backwards — left joystick.
2. Turn left / right — right joystick.
3. Rotate the upper body left.
4. Rotate the upper body right.
5. Power switch.
6. Raise / lower the blade (cycle).
7. Sound and lights on/off. Press again to stop.
8. Automatic demonstration.
9. Arm pushing action.
10. Arm digging action.



06 BATTERY CARE AND SAFETY

1. Insert batteries with the correct polarity.
2. Do not mix battery types or new and old batteries.
3. Use only the recommended battery types.
4. Do not short-circuit battery terminals.
5. Remove exhausted batteries.
6. Never recharge non-rechargeable batteries.
7. Remove the rechargeable pack before charging.
8. Charge under adult supervision.
9. Check the charging lead, plug and casing regularly. Stop using damaged equipment until repaired.
10. Keep fingers clear of sharp parts.
11. Do not break the controller antenna.

WARNING: **CHOKING HAZARD** — Small parts. Not suitable for children under 3 years.

Keep these instructions for future reference. • Made in China